



Installation instructions

- 1. Cut off the power and wear good gloves before assembling the lamp
- 2. The seven word copper (1) is fixed on the lamp body (2)
- 3. The top pulling head (4) is fixed on the ceiling with explosive screws (3)
- 4. The hanging plate (6) is fixed on the ceiling with explosive screws (5)
- 5. The external teeth telescopic iron part (7) is fixed on the top pulling force head (4)
- 6. Connect the driving wire to the light body wire, L to L, N to connect N  $\,$
- 7. The suction top plate (10) is fixed on the hanging plate
- (6) with a screw (9)

Matters needing attention:

- 1. This lamp just use indoor;
- $2.\,\mathrm{Pls}$  don't be charged before it is assembled;
- $3. \, \text{When you need to change the bulb, pls turn it off and wait the bulb to cool;} \, \text{Voltage:} 220 \text{V-} 240 \text{V}$

Bulb:LED 12V 300mA Lamp holder:Frequency

Caution:

Pls do use gasoline, alcohol and other corrosive drugs to clean the lamp, other it will damage the lamp.

Maintenance:

For useing the lamp better and safer, pls clean it regularly (once a month). Pls turn it off and wait for the body of lamp to be cooled before cleaning, And then use a soft cloth to dip in water and wring out water.